


Quick Start Guide

GV-Cloud VMS



Thank you for purchasing GV-Cloud VMS This guide is designed to assist the new user in getting immediate results from the GV-Cloud VMS. For advanced information on how to use the GV-Cloud VMS, please refer to *GV-Cloud VMS User's Manual*.



© 2025 GeoVision, Inc. All rights reserved.

Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of GeoVision.

Every effort has been made to ensure that the information in this manual is accurate. GeoVision, Inc. makes no expressed or implied warranty of any kind and assumes no responsibility for errors or omissions. No liability is assumed for incidental or consequential damages arising from the use of the information or products contained herein. Features and specifications are subject to change without notice.

GeoVision, Inc.

9F, No. 246, Sec. 1, Neihu Rd., Neihu District, Taipei, Taiwan

Tel: +886-2-8797-8377 Fax: +886-2-8797-8335

http://www.geovision.com.tw

Trademarks used in this manual: *GeoVision*, the *GeoVision* logo and GV series products are trademarks of GeoVision, Inc. *Windows* is the registered trademark of Microsoft Corporation.

August 2025

Scan the following QR codes for product warranty and technical support policy:





[Technical Support Policy]



Contents

1.	Introduction			
	1.2	Licenses Compatible Browsers Compatible GeoVision Products	2	
2.	Getting Started			
	2.1	Logging In	4	
	2.2	Adding Licenses	5	
	2.3	Creating Hosts	8	
	2.4	Connecting GV-VMS or GV-Al Guard	10	
	2.5	Connecting GV-Cloud Bridge or GV-Cloud Bridge Pro	12	
3.	Н	ome Page	14	



1. Introduction

Welcome to the *GV-Cloud VMS Quick Start Guide*. This quick guide will guide you through the basic settings of GV-Cloud VMS, including adding a license, creating a host, and connecting a host to GV-Cloud VMS. For more details, see *GV-Cloud VMS User's Manual*.

1.1 Licenses

GV-Cloud VMS has the following types of licenses. For details, please contact our sales representatives.

Plan			Basic	Standard	Premium
Price			Free	Licensing	Licensing
				by channel	by channel
Details	Details			Event	Cloud Backup
				Snapshot	-3/7/15/30
				– 30 Days	Days
Features	Live View		V	V	V
	Local Playback		V	V	V
	System Health		V	V	V
	Event Snapshot		-	V	V
	Share Link		-	V	V
	Archive		-	_	V
			_	_	By resolution:
	Cloud Ba	ackup			SD / 720p /
					2 MP / 4 MP
	Video	Motion	_	V	V
	Event	Event			
		Al Event	-	V	V
	Al	People &			
	Search	Vehicle	_	_	V
		Attributes			

For more information, see 1.4 Licenses in the user's manual.



1.2 Compatible Browsers

The following browsers are compatible with GV-Cloud VMS.

- Chrome
- Firefox
- Safari
- Microsoft Edge

Note: The WS player is not supported by Safari.



1.3 Compatible GeoVision Products

- **GV-VMS** (surveillance software): V18.3.2 + Patch or later; V17.4.7 + Patch or later
- **GV-Al Guard** (surveillance software): V2.1 or later
- GV-Cloud Bridge (encoder): firmware V1.03 or later
- GV-Cloud Bridge Pro (encoder): firmware V1.00 or later
- GV-Cloud Camera: GV-GBL4900, GBL4911, GDR4900, GEB4900, GEBF4911, GFER6900, GVD4910
- GV-SNVR (standalone system): to support in the future
- GV-Recording Server: to support in the future



2. Getting Started


To get started, you must acquire a *GV-Cloud VMS license* and a *series number* from GeoVision.

2.1 Logging In

- 1. Log into the GV-Cloud portal: https://www.gvaicloud.com/
- 2. Click Sign up.



- 3. On the Sign Up page, type the GV-Cloud user's Name, E-mail, mobile phone number (optional), and Password. Type the password again
- 4. Click **Agree** to accept the Terms of Use, Privacy Policy, and GDPR, and click **Sign Up**. You will receive a confirmation e-mail.
- 5. If you didn't receive a confirmation email, click the **Didn't receive the verification email?** button at the bottom of the Sign Up page.



- 6. To confirm the e-mail account, click the activation link in the confirmation e-mail. You will receive an additional e-mail confirming the success of GV-Cloud registration, along with an account ID number.
- 7. Log into GV-Cloud using the registered e-mail address and the account ID number.




IMPORTANT: Keep your account ID number, which is required each time you log into GV-Cloud.

Note: The mobile phone number can be used for the two-factor authentication if needed. See *5.1.3 Enabling Two-Factor Authentication* in the user's manual.

2.2 Adding Licenses

For first-time users, you need to add a license to start the services.

1. Click the Account icon S > Account Settings.




2. Select the **Subscription** icon in the left menu to open the page. Type your serial number, and click **Verify**.






 After verifying, you can click your plan to allocate licenses to cameras immediately, or click Skip for Now to assign them later. After assigning licenses, click Save to apply the settings.






- 4. Click Cloud VMS under Subscribed List to view your orders.
- 5. Click an order to expand and view plan details.
- 6. After adding hosts to GV-Cloud VMS, you can return to **Cloud VMS** under Subscribed List on the Subscription Management page, and enable or disable any cameras using the **License Cameras** option of each Plan.





IMPORTANT: All subscriptions are set to auto-renew by default, as indicated by the Auto-Renewal icon next to the order number. To cancel auto-renewal, click **Cancel Auto-Renewal** in the expanded view. Once canceled, the Auto-Renewal icon will be removed.



Note: Active subscriptions are listed under **Cloud VMS**, renewed subscriptions (including expired ones) under **Renew Requests**, and expired subscriptions under **History**.



2.3 Creating Hosts


You must create a host on *GV-Cloud VMS* for each GV-Cloud Camera, GV-VMS, GV-Al Guard, GV-Cloud Bridge, or GV-Cloud Bridge Pro that you want to connect to.

To create a host:

1. Click the **GV-Cloud Apps** icon at the top of the left menu, select **Cloud VMS**, and select the **Hosts** icon in the left menu to open the page.



2. Click the + icon. This dialog box appears.



3. Select a region from the Region drop-down list to categorize the host. See *5.2.1*Adding Regions in the user's manual for instructions on how to create regions.

Note:

- 1. Upon first login, a default region is automatically created, and any new hosts are grouped into this region.
- 2. Each host can only be assigned to a single region.



4. Type Display Name and Password (to be the host's GV-Cloud VMS login password). Alternatively, users can generate a random password by clicking Random Password. Select Time Zone for the host. The rest of the information is optional.

Note:

- 1. The display name must be at least 2 characters.
- 2. The password must be at least 8 characters long. It must contain three character categories among the following: uppercase letters (A-Z), lowercase letters (a-z), digits (0-9), and special characters (!^-,+[]=).
- Click Apply. The message "Host has been added" is displayed. Keep the Host Code and Password for configuring the connection to GV-Cloud on the host.



Note: To reset the password or change other host info, select a host in the Hosts list, and then click the **Edit Info** icon next to the **Info** tab. For details, see [Info], *4.1 Hosts* in the user's manual.




2.4 Connecting GV-VMS or GV-Al Guard

Follow the steps below to connect GV-VMS or GV-Al Guard to *GV-Cloud VMS* for cloud central monitoring.

Note: Events supported by GV-VMS / GV-Al Guard vary. The following instructions are exemplified by GV-VMS V18.

In GV-VMS / GV-Al Guard:

Click Home > Toolbar > Network > Connect to GV-Cloud. A dialog box appears.





- 2. Type a **Host Code** and **Password** created on GV-Cloud VMS. For details, see 2.3 *Creating Hosts*.
- 3. Click Connect.



In GV-Cloud VMS:

When the GV-Cloud VMS connection is established, the host will be displayed, with a yellow icon or a green icon, on the GV-Cloud VMS Home page.

Without a license, you can view live streaming from the host.

- 1. In the left menu, click the **Live Streaming** icon .
- 2. Expand the host in the host list.
- 3. Click a camera to see its live view.

By adding a license, you can receive snapshots or back up videos to GV-Cloud VMS. For details, see 2.2 Adding Licenses.

Note:

- If the GV-Cloud VMS connection fails in GV-VMS / GV-Al Guard, check to see if WebCam Server and Mobile Service are enabled alongside Connect to GV-Cloud.
- 2. For camera events, only motion and video lost will be sent to GV-Cloud VMS by default. To send additional camera event types to GV-Cloud VMS, see *2.4.1 Configuring Advanced Settings* in the user's manual.




2.5 Connecting GV-Cloud Bridge or GV-Cloud Bridge Pro

You can connect up to four ONVIF cameras, through GV-Cloud Bridge or GV-Cloud Bridge Pro, to *GV-Cloud VMS* for cloud central monitoring.

Note: To ensure a smooth playback on GV-Cloud VMS, it is suggested to connect a maximum of 2 cameras for the 4 MP license plan, 3 cameras for the 2 MP license plan, and 4 cameras for the 720p and SD license plan.

In GV-Cloud Bridge or GV-Cloud Bridge Pro:

1. In the left menu, select **Service Settings** > **GV-Cloud VMS**. This page appears.



- Enable Connection, and type a Host Code and Password created on GV-Cloud VMS.
 For details, see 2.3 Creating Hosts.
- 3. Click **Apply**. Once it is successfully connected, the State field will display "Connected".



In GV-Cloud VMS:

When the GV-Cloud VMS connection is established, the host will be displayed. with a yellow icon or a green icon on the GV-Cloud VMS Home page.

Without a license, you can view live streaming from the host.


- 1. In the left menu, click the **Live Streaming** icon ...
- 2. Expand the host in the host list.
- 3. Click a camera to see its live view.

By adding a license, you can receive snapshots or back up videos to GV-Cloud VMS. For details, see 2.2 Adding Licenses.



3. Home Page

The Home page offers centralized access to key features and status information in GV-Cloud VMS. This chapter provides an overview of its layout and functions.



No.	Name	Function	
1	GV-Cloud Apps	 Click the GV-Cloud Apps icon to access Cloud VMS, VPN, eMap, Audit Log, and Account Management. For VPN, see the user's guide. For eMap, see Chapter 7 E-Map. For Audit Log, see Chapter 6 Audit Log. For Account Management, see Chapter 5 Account Management. 	
2	Left Menu	Accesses these functions: Home, Hosts, Live Streaming, Playback, Query Events, Al Search, Share Links, Archives, Alert, and Operator Privileges. See Chapter 4 Cloud VMS Settings.	
3	Host List	Displays hosts along with their connection status. The host is disconnected. All the host's cameras are connected. Some cameras of the host are disconnected.	



		Note: A photo icon appears next to the cameras for the Standard license plan and a cloud icon appears for the Premium license plan.	
4	Cloud Account	 Accesses these functions: Logout: Log out the GV-Cloud account. Account Settings: This option allows you to change the GV-Cloud account's profile (Profile), password (Security), language setting / UI theme / time format (Appearances), as well as check and add subscriptions (Subscription). 	
5	Event Monitor	 Use the Filter above the Host List to display the events of specific hosts. Click an event to open the video window and view its snapshot, live view, and playback. See 3.1 Video Window. 	
6	Al Event Switch	Filters to display only AI events when enabled, while the default setting shows all detected events, including motion and AI.	
7	View Display	Displays motion and AI events in Photo View or List View.	

For details, see Chapter 3 Home Page in the user's manual.